




Manual Operating Instructions:

1. Mount clamp to fixture using two 1/2" or M12 Bolts.
2. Install provided 1/2-20 thrust screw (Clamping Torque, 38 ft-lbs), do not exceed manufacturer's recommended torque.

Hydraulic Operating Instructions:



3. Install Feeder Cap to 1/2-20 Threaded-Body Cylinder (Installation Torque, 7 ft-lbs).
4. Hand-Tighten 1/2-20 Threaded-Body Cylinder in to Body, no significant torque required (7ft-lbs or less).
5. If the clamp will be subjected to substantial vibration use a non-permanent thread locker to ensure the cylinder does not vibrate.
6. Never exceed 7,250 psi hydraulic pressure.

Questions? Call 1-800-785-7821 or email engineering@carrlane.com

***** Always use this product in the manner intended as found in the Carr Lane Mfg. Catalog or at carrlane.com**